Rouatronica

Instruction Manual



Water Leakage **Interface** ACQ210N-WL





Table of Contents

General Information	Page 3
Package Contents	Page 3
Connection diagram	Page 3
Connection to system	Page 3
Sensor state display	Page 5
Water Leakage Menu	Page 5
Disconnect	Page 8
Waste disposal legislation	
Warranty	
Declaration of conformity	

CHECK FOR ANY UPDATES ON THIS MANUAL ON THE WEBSITE

The water leakage sensor is a particularly useful accessory for aquarium enthusiasts.

Aquatronica recommends the product "Water Leakage Interface" which makes it possible to connect up to 2 water leakage sensors to the "Aquarium Controller" system.


This accessor's displays a digital value on 2 levels ("Dry" and "Wet") according to the sensor's state.

Package Contents

You will find:

- One WL probe connection interface.
- One BUS cable for connecting the interface to the power unit.
- One bag of accessories containing: 1 fixing bracket 1 kit of cable diameter adaptors – 1 guard – 2 fixing screws.

Connection diagram




NOTE: one or two water leakage sensors, without distinction, can be connected to the same interface.

Connection to "Aquarium Controller" system

- 1. Connect the WL probe's connector to the interface (ACQ210N-WL).
- Connect the WL interface to the power unit (or HUB) using the provided BUS cable.

NOTE: Insert the correct end of the connector into the power unit; inserting it in the other direction can seriously damage the equipment.

Thanks to the special shape of the box and fixing bracket, the interface can be fitted with others simply and very quickly, as seen below.



New device connected SO1 Water leakage

(Fig. 1)

After connection, the control unit will display a Plug-In screen (Fig. 1), where a name can be assigned to the connected sensor.

NOTE: The sensor's name can be changed using the control unit's keypad.

If more than one of these sensors is connected, the user may assign different names for each one to facilitate menu navigation.

Mon 07/05/07						15:05			
PU01	АВ	С	D	Ε	F	G	н		
Water	Leaka	ge				Dry	,		
(Fig. 2)									

Sensor state display

After the sensor has been connected through the appropriate interface, you can see its state on the main screen (Fig. 2).

If several sensors were connected, their states can be checked in order by pressing the keys \uparrow and \circlearrowleft .

Water leakage

Change Name Programs Alarm About

(Fig. 3)

Water Leakage Menu

Once the sensor and interface are connected, the "Water Leakage" menu will appear in the "Main Menu", where all of its settings can be programmed (Fig. 3). All the device setting menus are enabled only when the water leakage sensor is connected to the system.

Water leakage

(Fig. 4)

Change Name

This option modifies the name given to the sensor (Fig. 4).

To use this option, proceed as follows:

Main screen ☞ Main Menu ☞ Water Leakage ☞ Change Name.

Programs

Programs can be run depending on the state recorded by the sensor.

To insert a program, proceed as follows:

Main screen

Main Menu

Water Leakage

Programs.

• Select "Insert" using the ${}_{\square} \ \, {}_{\square}$ keys and press "Enter".

Insert

On this screen you can decide how to use the sockets depending on the state detected by the water leakage sensor (Fig. 5). You can decide to activate (when the socket is not highlighted and with the symbol above) or deactivate (when the socket is not highlighted but has only the symbol above – see Fig. 6) the outputs matching the water leakage sensor state.

To set this program, proceed as follows:

Main screen
Main Menu
Water Leakage Insert.

• Select the sensor state (OFF, Dry, Wet) with the \uphi keys.

Select the output you want to control with the ⟨¬¬⟩
keys. When finished, press "Enter" to store the program.

Water leakage
Insert

(Fig. 5)

	Programs						
Wet							
Ascent pump							
4							
PU01	ABCDÉFGH						
(Fig. 6)							

The example shown in figure 6 shows deactivation of socket "E" to which the ascent pump is connected every time the water leakage sensor takes on the "Wet" state.

Alarm					
Dry Wet	With Sound Without Sound				
	(Fig. 7)				

Alarm (Fig. 7)

A visual and acoustic alarm can be enabled in this menu to warn if the water leakage sensor takes on certain state.

When the "Wet" state is reached, the detected state blinks on the main screen if the alarm is set to "Without Sound".

If the alarm is set to "With Sound", the value will blink, an acoustic signal will sound and the icon \mathbb{Q} will appear on the main screen.

In addition to the blinking detected state, a blinking icon will appear on the main page indicating the alarm (\triangle) .

To program this function, proceed as follows:

Main screen → Main Menu → Water Leakage → Alarm.

Aquatronica FW Version: x.y Press any key to continue (Fig. 8)

About (Fig. 8)

Provides information on the control unit's firmware version.

To use this function, proceed as follows:

Main screen ☞ Main Menu ☞ Water Leakage ☞ About.

WARNING

PREVENT THE SENSOR FROM COMING INTO CONTACT WITH HANDS OR CONDUCTOR MATERIALS (E.G. METALS)

Device Disconnected

Disconnect

If the water leakage sensor is disconnected, a message will appear on the display (Fig. 9). Press **"Enter**" to indicate that the message has been read.

S01: Water leakage

(Fig. 9)



On the main screen the "?" icon will appear next to the word "Water Leakage" and in the lower left corner (Fig. 10).

If the water leakage sensor is reconnected, the control unit will automatically begin displaying the read state again.

DISPOSAL OF ELECTRIC AND ELECTRONIC PARTS

Pursuant to Article 13 of Legislative Decree No. 151 of 25 July 2005, "Implementation of *Directives 2002/95/CE, 2002/96/CE and 2003/108/CE regarding the reduction in use of dangerous substances in electrical and electronic equipment, as well as waste disposal":*



_ ({ Products bearing the barred dustbin symbol must be disposed of separately from other waste.

The user must therefore dispose of the product in question at suitable recycling centers for electronic and electro-technical waste, or he/she must turn over the used product to the retailer when buying a new equivalent product, on a one-to-one basis.

Separate waste collection allows used equipment to be recycled, treated and disposed of without negative consequences for the environment and health, and it allows the materials in the equipment to be recycled. Illegal dumping of the product by the user entails the administrative sanctions stated in Legislative Decree No. 22/1997 (Article 50 et seq of Legislative Decree No. 22/1997).



Separate collection of used products and packaging allows materials to be recycled and used again. Reuse of recycled materials helps prevent environmental pollution and reduces the demand for raw materials.

Local regulations may provide for the separate collection of household appliances at municipal waste sites or retailers when a new product is purchased.

Warranty

Dear Customer.

Thank you for the trust you have placed in **AQUATRONICA** by purchasing this product. **AQUATRONICA** subjects all its products to severe quality tests. If, in spite of the controls, the product should malfunction, we recommend you immediately contact the dealer/producer for any checks or interventions necessary.

- General warranty regulations

AQUATRONICA guarantees that this product operates properly and that it is free of manufacturing faults and defects. If the product becomes defective during the warranty period, AQUATRONICA will repair or replace it. Defective parts will be replaced ex-works AQUATRONICA's plant (recipient responsible for shipping expenses). Accessories and components not made by AQUATRONICA are covered by their manufacturers' warranties only. This is the only warranty offered by AQUATRONICA. All others are excluded. Unless due to malice or gross negligence, AQUATRONICA is not responsible for injury to people or damage to things resulting from product malfunctioning.

This warranty is valid only for those up to date with their payments.

- Conditions

The warranty will be valid for a period of 24 months from the date of purchase only upon presentation of this certificate, which must bear the retailer's stamp, the date of sale and the product's serial number, accompanied by the invoice or receipt issued by the retailer, indicating the serial numbers of the installed products. AQUATRONICA can refuse to recognize the warranty if this information is incomplete or has been tampered with after purchase. The warranty will be valid only if, at the time of purchase, the product was properly stored as it was originally packaged by AQUATRONICA, who alone can ensure its origin and adequate protection.

- Warranty exclusions

This warranty does not cover:

a) periodic checks, maintenance, repairs, or replacement of parts due to normal wear;

b) malfunctioning due to negligence, incorrect installation, improper use or non-observance of the technical instructions and, in general, any malfunction not traceable to manufacturing faults or defects of the product and therefore the responsibility of AQUATRONICA;

 c) products modified, repaired, replaced, installed or in any way tampered with by anyone without the prior written authorization of AQUATRONICA;

 d) accidents originating from force majeure or other causes (e.g. water, fire, lightning, bad ventilation, etc.) not depending on AQUATRONICA.

Products with manufacturing faults or defects recognizable through normal diligence must not be resold or installed. The sole competent court for any disputes concerning the interpretation or execution of this warranty is that of Reggio Emilia (Italy).

Product code:								
Serial number:								
Date of purchase:	Day		Мо	nth	[Ye	ar	

Retailer's stamp

Declaration of Conformity

DECLARATION OF CONFORMITY

Standard of reference ISO/IEC Guide 22 and EN 45014

Number of conformity: 005-2007/E

Name of the manufacturer: Address:

Aquatronica division of A.E.B. srl

via dell'Industria, 20 Corte Tegge 42025 Cavriago (RE) Italy

DECLARES THAT THE ELECTRONIC UNITS

Code:

ACQ210N-RX (REDOX sonde interface) ACQ210N-PH (PH sonde interface)

ACQ210N-TL (temperature and level sonde interface)
ACQ210N-MS (conducibility sonde interface)

ACQ210N-D (density sonde interface)

ACQ210N-WL (water-leakage sonde interface)

ARE IN COMPLIANCE WITH THE FOLLOWING PRODUCT SPECIFICATIONS:

FIELD	Directive	Description	References	Test Result
EMC	2004/108/EC	EMC directive	Official Journal of the European Union L390 December 31 2004	applied

THEREFORE THEY ARE IN COMPLIANCE WITH THE REQUISITES OF THE CE MARK
The equipment was checked in a typical working configuration

Place of issue: Cavriago (RE) Italy

Date of issue: 12/04/07

The A.E.B. sri legal representative

AStali ha

Rouatronica

A.E.B. Srl Division

Via dell'Industria, 20 - 42025 Cavriago (RE) Italy Tel.: +39 0522 494403 Fax: +39 0522 494410 http://www.aquatronica.com E=mail: service@aquatronica.com